

1. Supplied spindle
Ensure the spindle is inserted with the groove (1A) facing the grub screw (7)
2. Sprung cartridge
Note the back portion of the cartridge (2A) is to be recessed into the door
3. Back to back bolts & wood screws
The back to back bolts (3A) are to be located to the left and right of the spindle. The wood screws (3B) are to be located above and below the spindle
4. Outer rose cover
5. Nylon washer
6. Lever handle
7. Grub screw

Note: We strongly recommend requesting a sample before committing to any cutting or drilling

